

## WSC1068

### Weatherstrip Coating

*Before processing this product please read the associated Safety Data Sheet (SDS) for each component and observe good manufacturing practices.*

#### Coating Preparation:

1. When using weatherstrip coatings it is important that any settled matting agent, or friction modifiers, be brought back into suspension before use.

After opening a pail of WSC1086A, a spatula or rod must be used to loosen any deposits at the bottom of the container. Once this is complete, thoroughly mix the substance using a paddle blade stirrer that rotates at 30 - 100 rpm for a minimum of 10 minutes. The level of the stirrer needs to be regulated so that the substance can be mixed thoroughly with little to no foam generated.

2. The diluting water, if used, and catalyst (WSC1068B) are then added while the base is gently stirring. The additions are based on weight. The two components are supplied pre-weighed at 16 Kg. The A component at 16 Kg is mixed with 600 g of the B component. The coating mixture is then placed under the stirrer for an additional 10 minutes. To eliminate potential blockages caused by dry material falling back into the coating solution, filtration, using a 200 micron disposable filter mesh, is recommended when transferring the coating from the mixing vessel to the delivery container. An alternate option is to install a filter in-line in the application tubing after the pump or pressure pot. The coating is then ready to use. Note, all equipment used should be washed with clean water following this process.

3. **IMPORTANT:** If the coating of the water-based systems is following a solvented system, it is necessary to clean all parts that come in contact with the coating with the carrier solvent used for the first coating, followed by acetone or iso-propanol and finally clean water to ensure all traces of the first coating and solvent are removed from the spray installation. Failure to follow this routine can result in gun blockages and instability of the WSC1068 coating. If possible, an easier and more effective solution would be to exchange all the delivery pipework with new pipework. It is also recommended to thoroughly clean the tubes, pumps and spray guns if a different chemistry of coating has been used. Do not mix polyurethane, silicone or hybrid coatings because they are generally not compatible.

#### Application:

1. The coating can be applied by using any of the following methods:
  - Hand spray** - using a HVLP gravity feed pistol
  - Robotic off-line spray** - using electrostatic or HVLP gun
  - On-line - using single or multiple guns** (determined by the profile to be coated)
  - Drip and brush** - preferably using long bristles

All the above can be used in conjunction with pressure pot, gear pump or peristaltic pumps to feed coating to the application point.

2. If conventional HVLP equipment is used, the air cap should be 0.8-1.2 mm in diameter. If needleless guns are used, a nozzle diameter of 0.6-0.8 mm is recommended.
3. The part temperature should be between 80°C and 180°C at the point where the coating is applied (colder will produce a slightly more gloss surface).

### **Coating:**

1. The fluid flow, atomizing pressure and distance of the gun to the part will have a major impact on the finished film appearance and should be adjusted accordingly to give the desired effect.
2. The coating should be applied so that it achieves a 'wet' appearance at the coating station, but not excessively thick. The coating should be almost dry before the curing cycle.

If multiple guns are used, it is important to apply the additional coatings while the original coating is still wet. This helps to achieve a good surface on the finished part. It is advised that the coating equipment be set up to minimize overspray and maximize use of the coating.

### **Curing:**

1. Cure of the coating is a function of the coating thickness, time and temperature and is determined by the oven type, efficiency of the oven and part construction.
2. During the cure the part temperature should not exceed 200°C, otherwise degradation of the rubber surface can occur. Typical cure indications are 160°C for 2 minutes; 140°C for 4 minutes; 100°C for 7 minutes and 80°C for 10 minutes. These figures refer to the part temperature, NOT the air temperatures indicated on the ovens.
3. As the part exits production, initial evaluation of the coating is made by stretching the part and looking for cracking of the weatherstrip coating. A cross-hatch adhesion test is performed. Each of these routine examinations are able to quickly indicate problems of adhesion. Full laboratory testing will not give dependable results until 24 hours after coating, when the parts are fully cured and cold.
4. As an indication of correct cure, a cotton bud dipped in solvent naphtha (lighter fluid) can be rubbed with light pressure on the coated surface. Both the cotton and profile can be examined to determine if any coating removal or black staining on the cotton is present. If so, this would indicate under cure of the coating. If fully cured, no marking or staining will be present on the cotton.

## **Evaluation:**

1. Visual examination of the coating should be made at the start of the production to ensure the spray (or other application method) is acceptable.

## **Common defects include:**

- Heavy coating in grooves of the profile resulting in blisters - move guns further away from part or reduce coating flow to this area
- Heavy coating where sprays overlap - move spray pistols for better coverage
- Light coating in certain areas of the part - move spray pistols closer or increase coating flow to that area
- Spots showing in coating - guns too close or atomizing pressure too low
- Rough surface on coating - extreme result of above
- Runs in coating - guns too close or too much wet coating being applied
- Poor adhesion on sponge rubber- part too hot at point of coating (on-line)
- Poor adhesion on solid rubber- free oils in rubber formulation (off-line) solvent wash to clean the surface before coating and use a primer

## Contact Information

For product prices, availability or order placement, contact customer service at [Momentive.com/contact/customer-service](http://Momentive.com/contact/customer-service)

For literature and technical assistance, visit our website at: [www.momentive.com](http://www.momentive.com)

## Telephone

<b>Americas</b>	<b>EMEA</b>	<b>China</b>	<b>Japan</b>	<b>South Korea</b>	<b>South East Asia, Australia &amp; New Zealand</b>
+1 800 295 2392 +1 704 805 6946	+40213 044229	800 820 0202 +8621 38604892	0120 975 400 +81 276206182	+82 2 6201 4600	+60 3 9206 1543

## DISCLAIMER:

THE MATERIALS, PRODUCTS AND SERVICES OF MOMENTIVE PERFORMANCE MATERIALS INC. AND ITS SUBSIDIARIES AND AFFILIATES (COLLECTIVELY "SUPPLIER"), ARE SOLD SUBJECT TO SUPPLIER'S STANDARD CONDITIONS OF SALE, WHICH ARE INCLUDED IN THE APPLICABLE DISTRIBUTOR OR OTHER SALES AGREEMENT, PRINTED ON THE BACK OF ORDER ACKNOWLEDGMENTS AND INVOICES, AND AVAILABLE UPON REQUEST. ALTHOUGH ANY INFORMATION, RECOMMENDATIONS, OR ADVICE CONTAINED HEREIN IS GIVEN IN GOOD FAITH, SUPPLIER MAKES NO WARRANTY OR GUARANTEE, EXPRESS OR IMPLIED, (i) THAT THE RESULTS DESCRIBED HEREIN WILL BE OBTAINED UNDER END-USE CONDITIONS, OR (ii) AS TO THE EFFECTIVENESS OR SAFETY OF ANY DESIGN INCORPORATING ITS PRODUCTS, MATERIALS, SERVICES, RECOMMENDATIONS OR ADVICE. EXCEPT AS PROVIDED IN SUPPLIER'S STANDARD CONDITIONS OF SALE, SUPPLIER AND ITS REPRESENTATIVES SHALL IN NO EVENT BE RESPONSIBLE FOR ANY LOSS RESULTING FROM ANY USE OF ITS MATERIALS, PRODUCTS OR SERVICES DESCRIBED HEREIN.

Each user bears full responsibility for making its own determination as to the suitability of Supplier's materials, services, recommendations, or advice for its own particular use. Each user must identify and perform all tests and analyses necessary to assure that its finished parts incorporating Supplier's products, materials, or services will be safe and suitable for use under end-use conditions. Nothing in this or any other document, nor any oral recommendation or advice, shall be deemed to alter, vary, supersede, or waive any provision of Supplier's standard Conditions of Sale or this Disclaimer, unless any such modification is specifically agreed to in writing signed by Supplier. No statement contained herein concerning a possible or suggested use of any material, product, service or design is intended, or should be construed, to grant any license under any patent or other intellectual property right of Supplier covering such use or design, or a recommendation for the use of such material, product, service or design in the infringement of any patent or other intellectual property right.

Momentive is a registered trademark of Momentive Performance Materials Inc.



260 Hudson River Road  
Waterford, NY 12188 USA  
[www.momentive.com](http://www.momentive.com)

Copyright 2020 Momentive Performance Materials Inc. All rights reserved.